



■ ステージ

① K-030	W1800 x D900 x H100
② K-025	W1100 x D600 x H100




■ ステージ

③ K-020	W1800 x D900 x H150
④ K-022	W180 x D900 x H300




■ ステージ

⑤ K-021	W900 x D900 x H150
⑥ K-023	W900 x D900 x H300




■ ステージ

⑦ K-024	W450 x D450 x H450	⑨ K-027	W900 x D450 x H450
⑧ K-026	W600 x D450 x H450	⑩ K-028	W1200 x D450 x H450



■ サイコロBOX 450角

① K-032	W450 x D450 x H150	③ K-024	W450 x D450 x H450
② K-032	W450 x D450 x H300	④ K-031	W450 x D450 x H600




■ サイコロBOX 600角

① K-033	W600 x D600 x H150	③ K-035	W600 x D600 x H450
② K-034	W600 x D600 x H300	④ K-036	W600 x D600 x H600




■ Rステージ

① R-001	W900 x D900 x H300
② R-002	W900 x D900 x H150



■ Rステージ

③ R-003	1200φ x H150
④ R-004	900φ x H150



■ Rステージ

⑤ R-005	W620φ x H300
⑥ R-007	W620φ x H150
⑦ R-008	W515φ x H300
⑧ R-009	W515φ x H200
⑨ R-010	W620φ x H75

